






















Galpa Export DANFOSS FREQUENCY CONVERTERS

<p>G175G5539</p>  <p>Danfoss Soft Starter MCD 500 175G5539 200-525 Vac, 380A, AC53a</p>	<p>G131F5460</p>  <p>DANFOSS VLT 15HP 200-240V 46.2A 20IP FC-102P11KT2E20H2XGX</p>	<p>G131F0426</p>  <p>DANFOSS VLT 15HP 380-480V 24.0A 20IP FC-102P11KT4E20H2XGX</p>	<p>G175G5233</p>  <p>DANFOSS VLT 25HP 200-525V 42A 20IP MCD202018T6CV3</p>	<p>G131H5694</p>  <p>DANFOSS VLT 30HP 200-240V 88.0A 20IP FC-102P22KT2E20H2XGX</p>
<p>G131F6626</p>  <p>DANFOSS VLT 30HP 380-480V 44.0A 20IP FC-102P22KT4E20H2XGX</p>	<p>G131B7004</p>  <p>DANFOSS VLT 50HP 380-480V 73.0A IP21 37KW FC-102P37KT4E21H2XGXXXXXX</p>	<p>G131F6756</p>  <p>DANFOSS VLT 50HP 380-480V 73.0A IP66 37KW FC-102P37KT4E66H2XGXXXXXX</p>	<p>G131B0003</p>  <p>DANFOSS VLT AUTOMATION DRIVE FC-302 7.5kW IP20 FC-302P7K5T5E20H1XXXXXX</p>	<p>G132F0003</p>  <p>DANFOSS VLT FC-051 0.75KW 200-2400V AXBXCXXXXX</p>
<p>G132F0059</p>  <p>DANFOSS VLT FC-051 15KW/31AMPS 20HP 380-480V</p>	<p>G131B9826</p>  <p>DANFOSS VLT FC-302 11kW 3X380-500V IP20 FC-302P11KT5E20H1XGXXXXXX</p>	<p>G131B0328</p>  <p>DANFOSS VLT FC-302 3.7KW 200-240V FC-302P3K7T5E20H1B</p>	<p>G131B0070</p>  <p>DANFOSS VLT FC-302 4.0KW/10AMPS 380-500V IP20 FC-302P4K0T5E20H2BGXXXXXX</p>	<p>G131B0004</p>  <p>DANFOSS VLT FC-302 7.5KW 380-500V FC-302P7K5T5E20H1BXX AXBXCXXXXX</p>
<p>G131B0042</p>  <p>DANFOSS VLT FC-302 7.5KW/16AMPS 380-500V</p>	<p>G131L9798</p>  <p>DANFOSS VLT HVAC FC-101 5.5KW/ 200-240V, IP20, RFI A1 FC-101P5K5T2E20H4XXCXXXXXX</p>	<p>GMCD5-0141B</p>  <p>DANFOSS VLT MCD5-0141B SOFT STARTER 96A 75HP / 440V AXBXCXXXXX</p>	<p>G195N1123</p>  <p>DANFOSS VLT-2881 20HP 15KW 380-480V / 195N1123</p>	