



Galpa Export WHIRLPOOL RANGE/STOVE/OVEN PARTS

<p>G2002.W20</p> <p>2002.W20</p>	<p>G2002.W53</p> <p>2002.W53</p>	<p>G4451231</p>  <p>4451231</p>	<p>G865940</p>  <p>BAKE ELEMENT WHIRLPOOL 865940</p>	<p>G4338568</p>  <p>BASE DRIP PAN WHIRLPOOL "FSP" 4338568 / WB32X102</p>
<p>GW10196406</p>  <p>BOWL CHROME 6" WITH HOLE WHIRLPOOL WPW10196406 / 3195208</p>	<p>GW10196405</p>  <p>BOWL CHROME 8" WITH HOLE WHIRLPOOL WPW10196405 / 3195209</p>	<p>GW10290353</p>  <p>BOWL PORCELAIN 6" WITH HOLE WHIRLPOOL W10290353 / WPW10290353</p>	<p>GW10290350</p>  <p>BOWL PORCELAIN 8" WITH HOLE WHIRLPOOL W10290350 / WPW10290350</p>	<p>G98005518</p>  <p>BURNER CAP WHIRLPOOL 98005518</p>
<p>G98005519</p>  <p>BURNER CAP WHIRLPOOL 98005519</p>	<p>G98017462</p>  <p>BURNER CAP WHIRLPOOL 98017462</p>	<p>G3191904</p>  <p>BURNER CAP WHIRLPOOL FRONT 3191904</p>	<p>G3191901</p>  <p>BURNER CAP WHIRLPOOL REAR 3191901</p>	<p>GW10183368</p>  <p>BURNER CAP WHIRLPOOL REAR W10183368</p>
<p>GW10183369</p>  <p>BURNER CAP WHIRLPOOL REAR W10183369</p>	<p>GW10183370</p>  <p>BURNER CAP WHIRLPOOL REAR W10183370</p>	<p>GW10118216</p>  <p>BURNER CAP WHIRLPOOL W10118216</p>	<p>G12001074</p>  <p>BURNER MAYTAG 12001074</p>	<p>G12001075</p>  <p>BURNER MAYTAG 12001075 / 7507P136-60 / 7507P134-60 / 5187D03160 / 5187D02760 / 5187M027-60 / 7507P136-60 / 7507P135-60 / 7507P134-60 /</p>
<p>G3186478</p>  <p>BURNER WHIRLPOOL 3186478</p>	<p>G74003963</p>  <p>BURNER WHIRLPOOL 74003963 / 3412D024-09/ 12500050 / WP3412D024-09</p>	<p>G74010149</p>  <p>BURNER WHIRLPOOL 74010149 / WP74010149</p>	<p>G8053360</p>  <p>BURNER WHIRLPOOL 8053360</p>	<p>G8053463</p>  <p>BURNER WHIRLPOOL 8053463 (DISCONTINUED)</p>
<p>G98003939</p>  <p>BURNER WHIRLPOOL 98003939 / WP98003939 (DISCONTINUED)</p>	<p>G98015950</p>  <p>BURNER WHIRLPOOL 98015950</p>	<p>G74003965</p>  <p>BURNER WHIRLPOOL GREY 74003965 / 3412D024-26</p>	<p>GW10125641</p>  <p>BURNER WHIRLPOOL W10125641 / 7504P00160K</p>	<p>GW10132045</p>  <p>BURNER WHIRLPOOL W10132045</p>



Galpa Export WHIRLPOOL RANGE/STOVE/OVEN PARTS

<p>GW10132046</p>  <p>BURNER WHIRLPOOL W10132046 / W10116248 / W10243402 / 98017538</p>	<p>GW10270804</p>  <p>BURNER WHIRLPOOL W10270804</p>	<p>G74003332</p>  <p>BURNER WHIRLPOOL WP74003332 / 74003332 / 74002392</p>	<p>G74010148</p>  <p>BURNER WHIRLPOOL WP74010148 / 74010148</p>	<p>G98016327</p>  <p>BURNER WHIRLPOOL 98016327</p>
<p>G98015032</p>  <p>CLIP ELECTRODE WHIRLPOOL 98015032</p>	<p>GW10278150</p>  <p>CLIP ELECTRODE WHIRLPOOL WPW10278150 / W10278150 / 98015032</p>	<p>G12001393</p>  <p>COOK TOP WHIRLPOOL 12001393</p>	<p>G3187940</p>  <p>DOOR HANDLE 3187940 / WP3187940</p>	<p>GW10155557</p>  <p>DOOR OVEN KITCHENAID W10155557</p>
<p>GWP8053334</p>  <p>DRAWER GLIDE STOVE WHIRLPOOL WP8053334 / 8053334 / 3195062</p>	<p>GWPW10114344</p>  <p>DRAWER GLIDE STOVE WHIRLPOOL WPW10114344</p>	<p>G4396388</p>  <p>FILTER PAR RANGE HOOD WHIRLPOOL 4396388 / WP4396388</p>	<p>G31001485</p>  <p>GAS BURNER MAYTAG 31001485</p>	<p>G8281918</p>  <p>GAS VALVE ASSEMBLY WHIRLPOOL 8281918</p>
<p>G9761557CB</p>  <p>GRIDDLE KITCHENAID 9761557CB</p>	<p>G8053895</p>  <p>GRIDDLE WHIRLPOOL 8053895 / 8053455 / WP8053455</p>	<p>G8053896</p>  <p>GRIDDLE WHIRLPOOL 8053896 / 8053456 / WP8053456</p>	<p>G5303271409</p> <p>HEATER DEFROST FRIGIDAIRE 5303271409 (DISCONTINUED)</p>	<p>G98010972</p>  <p>HOSE CONNECTOR WHIRLPOOL 98010972</p>
<p>GW10160375</p>  <p>KNOB KITCHENAID W10160375</p>	<p>G8273108</p>  <p>KNOB WHIRLPOOL 8273108</p>	<p>G98016471B</p> <p>KNOB WHIRLPOOL 98016471B (DISCONTINUED)</p>	<p>G98016471S</p>  <p>KNOB WHIRLPOOL 98016471S</p>	<p>GW10058970</p>  <p>KNOB WHIRLPOOL W10058970</p>
<p>GW10118492</p>  <p>KNOB WHIRLPOOL W10118492</p>	<p>GW10198948</p>  <p>KNOB WHIRLPOOL W10198948</p>	<p>GW10198950</p>  <p>KNOB WHIRLPOOL W10198950</p>	<p>GW10198951</p>  <p>KNOB WHIRLPOOL W10198951</p>	<p>GW10198952</p>  <p>KNOB WHIRLPOOL W10198952</p>

































Galpa Export WHIRLPOOL RANGE/STOVE/OVEN PARTS

<p>GW10198953</p>  <p>KNOB WHIRLPOOL W10198953</p>	<p>GWPW10591270</p>  <p>LP CONVERSION KIT WHIRLPOOL W10591270</p>	<p>G8184719</p>  <p>MICROCOMPUTER 8184719 (OBSOLETE)</p>	<p>G4452240</p>  <p>MICROCOMPUTER WHIRLPOOL 4452240 (DISCONTINUED)</p>	<p>GW10312205</p>  <p>MICROCOMPUTER WHIRLPOOL W10312205</p>
<p>GW10308477</p>  <p>OVEN BAKE ELEMENT WHIRLPOOL W10308477 / WPW10308477</p>	<p>G316557115</p>  <p>OVEN CONTROL BOARD 316557115</p>	<p>G4451991</p>  <p>OVEN CONTROL BOARD 4451991 / 8302967 / WP8302967</p>	<p>G8300795</p>  <p>OVEN CONTROL BOARD 8300795</p>	<p>G8302994</p>  <p>OVEN CONTROL BOARD 8302994 / WP8302994</p>
<p>G6610309</p>  <p>OVEN CONTROL BOARD MICROCOMPUTER WHIRLPOOL 6610309 / WP6610457</p>	<p>G8303885</p>  <p>OVEN CONTROL BOARD WHIRLPOOL 8303885 / 8303505 / WPW10340935</p>	<p>GWPW10424330</p>  <p>OVEN CONTROL BOARD WHIRLPOOL W10424330</p>	<p>G814412</p>  <p>OVEN SAFETY VALVE WHIRLPOOL 814412</p>	<p>G9761959</p>  <p>OVEN SAFETY VALVE WHIRLPOOL 9761959 / WPW10293048</p>
<p>G98011275</p>  <p>OVEN SAFETY VALVE WHIRLPOOL. MLI-VOLTIOS 98014016 / 98011275</p>	<p>G12001676</p>  <p>PORCELAIN RECEPTACLE MAYTAG 12001676</p>	<p>G3195008</p>  <p>RANGE GAS VALVE WHIRLPOOL W / REGULATOR ASSEMBLY 3195008</p>	<p>G660532</p>  <p>RANGE HEATER ELEMENT 4T 6" 240V WHIRLPOOL 660532 / WP660532</p>	<p>G660533</p>  <p>RANGE HEATER ELEMENT 5T 8" 240V WHIRLPOOL 660533 / WP660533</p>
<p>GW10259865</p>  <p>RANGE HEATER ELEMENT 5T 8" 240V WHIRLPOOL W10259865 / 9761345 / WPW10259865</p>	<p>G12002142</p>  <p>RANGE HEATER ELEMENT WHIRLPOOL 12002142 SURFACE TOP WP8523694</p>	<p>G3189895</p>  <p>RANGE HEATER ELEMENT WHIRLPOOL 1700W 3189895 / 8185644 / 8203568 / WP8203568 3169544 / 8203531 / 9751529</p>	<p>G8523696</p>  <p>RANGE HEATER ELEMENT WHIRLPOOL 1800 WATTS 8523696 / W10823698</p>	<p>G8286187</p>  <p>RANGE HEATER ELEMENT WHIRLPOOL 8286187 / WP8286187</p>
<p>G3189894</p>  <p>RANGE HEATER ELEMENT WHIRLPOOL W10212682 / 1472249 / 3169543 / 3189894 / 8185646 / AH2342231 / EA2342231 / PS2342231 / B002ZNA0TQ /</p>	<p>G8523047</p>  <p>RANGE HEATER ELEMENT WHIRLPOOL WP8523047</p>	<p>GWPW10242957</p>  <p>RANGE HEATER ELEMENT WHIRLPOOL W10242957 / W10242957 / 8523695 / 8272568 / 8053622 / 4389679 / 4343210 / 4343098</p>	<p>G3183120</p>  <p>RANGE KNOB BLACK 3183120 (DISCONTINUED)</p>	<p>G3196231</p>  <p>RANGE KNOB BLACK 3196231</p>



Galpa Export WHIRLPOOL RANGE/STOVE/OVEN PARTS

<p>G3150371</p>  <p>RANGE KNOB BLACK WHIRLPOOL 3150371</p>	<p>G3150373</p>  <p>RANGE KNOB BLACK WHIRLPOOL 3150373</p>	<p>G3150374</p>  <p>RANGE KNOB BLACK WHIRLPOOL 3150374</p>	<p>G8273103</p>  <p>RANGE KNOB BLACK WHIRLPOOL 8273103</p>	<p>G3196233</p>  <p>RANGE KNOB CREAM 3196233</p>
<p>G3196232</p>  <p>RANGE KNOB WHITE 3196232</p>	<p>G3150372</p>  <p>RANGE KNOB WHITE WHIRLPOOL 3150372</p>	<p>G3183119</p>  <p>RANGE KNOB WHITE WHIRLPOOL 3183119</p>	<p>G8273104</p>  <p>RANGE KNOB WHITE WHIRLPOOL 8273104</p>	<p>G4454537</p>  <p>RANGE SWITCH WHIRLPOOL 2400W 4454537 (DISCONTINUED)</p>
<p>G4454535</p>  <p>RANGE SWITCH WHIRLPOOL 454535 (DISCONTINUED)</p>	<p>G8203534</p>  <p>RANGE SWITCH WHIRLPOOL 8203534</p>	<p>G9750589</p>  <p>RANGE SWITCH WHIRLPOOL 9750589</p>	<p>G3149404</p>  <p>RANGE SWITCH WHIRLPOOL WP3149404 / 3149404 / 3148951 / 3148952</p>	<p>GWP7403P238-60</p>  <p>RANGE SWITCH WHIRLPOOL WP7403P238-60 / 7403P238-60 / 7403P37360 / 7403P26260 / 7403P23860 / 7403P373-60 / 7403P262-60</p>
<p>G4450249</p>  <p>RANGE THERMOSTAT WHIRLPOOL 4450249</p>	<p>G4451442</p>  <p>RANGE THERMOSTAT WHIRLPOOL WP9759243 / 4451442 / 9759243</p>	<p>G8053344</p>  <p>SENSOR OVEN TEMPERATURE 8053344</p>	<p>G98016567B</p>  <p>SKIRT KNOB WHIRLPOOL 98016567B</p>	<p>G98016567S</p>  <p>SKIRT KNOB WHIRLPOOL 98016567S</p>
<p>G3150505</p>  <p>SOCKET / LIGHT AND LENS. WHIRLPOOL 3150505</p>	<p>G4456901</p>  <p>SPARK IGNITION SWITCH WP4456901</p>	<p>G98003951</p>  <p>SPARK MODULE 6 POSITION WHIRLPOOL 98003951 / W10110489 / WPW10110486</p>	<p>G98015210</p>  <p>SPARK MODULE 8 POSITION WHIRLPOOL 98015210 / 98004303</p>	<p>G4451934</p>  <p>SUPPRESSOR WHIRLPOOL 4451934 / WP4451934</p>
<p>G9763765</p>  <p>SWITCH RANGE WHIRLPOOL 9763765 / WP9763765</p>	<p>G4451665</p>  <p>THERMOCUPLON OVEN WHIRLPOOL 4451665</p>	<p>G12400035</p>  <p>WHIRLPOOL OVEN IGNITER 12400035</p>	<p>G4342528</p>  <p>WHIRLPOOL OVEN IGNITER 4342528</p>	<p>G98005652</p>  <p>WHIRLPOOL OVEN IGNITER W10918546 / 98005652</p>



Galpa Export
WHIRLPOOL RANGE/STOVE/OVEN PARTS

G3186491



WHIRLPOOL OVEN IGNITER
WP31001556

G98008959



WHIRLPOOL OVEN IGNITOR
W10209656 / 98008959 /
98014514

G330031



WHIRLPOOL TERMINAL BLOCK
330031