



**Galpa Export**  
**GENERAL ELECTRIC RANGE/STOVE/OVEN PARTS**

<p><b>GWB31M16</b></p>  <p>BOWL CHROME 6" WITH HOLE G.E. WB31M16</p>	<p><b>G1875.226G</b></p>  <p>BOWL CHROME 6" WITH HOLE G.E. WB31X5010B</p>	<p><b>GWB32X10012</b></p>  <p>BOWL CHROME 6" WITH HOLE G.E. WB32X10012</p>	<p><b>GWB31M15</b></p>  <p>BOWL CHROME 8" WITH HOLE G.E. WB31M15</p>	<p><b>G1875.228G</b></p>  <p>BOWL CHROME 8" WITH HOLE G.E. WB31X5011B</p>
<p><b>G1875.446</b></p>  <p>BOWL PORCELAIN 6" WITH HOLE SMP6NP / WB31M20</p>	<p><b>G1875.448</b></p>  <p>BOWL PORCELAIN 8" WITH HOLE SMP8NP / WB31M19</p>	<p><b>GWB16K-10026</b></p>  <p>BURNER DOUBLE G.E. WB16K10026</p>	<p><b>GWB16K10062</b></p>  <p>BURNER G.E. WB16K10062</p>	<p><b>GWB28X39</b></p>  <p>BURNER G.E. WB28X39 (NO LONGER AVAILABLE)</p>
<p><b>GWB28X40</b></p> <p>BURNER G.E. WB28X40 (NOT LONGER AVAILABLE)</p>	<p><b>GWB16T10046</b></p>  <p>BURNER LARGE G.E. WB16T10046</p>	<p><b>GWB16K10055</b></p>  <p>BURNER MEDIUM G.E. WB16K10055</p>	<p><b>GWB27T10365</b></p> <p>Cook top Main Control Board G.E. WB27T10365</p>	<p><b>GWB28K10024</b></p>  <p>FRONT BURNER TUBE G.E. WB28K10024</p>
<p><b>GWB28K10025</b></p>  <p>FRONT BURNER TUBE G.E. WB28K10025</p>	<p><b>GWB2X9998</b></p>  <p>IGNITOR WB2X9998</p>	<p><b>GWB21X5243</b></p>  <p>INFINITE SWITCH G.E. WB21X5243</p>	<p><b>GWB03K10305</b></p>  <p>KNOB G.E. WB03K10305</p>	<p><b>GWB28K10031</b></p>  <p>LPG CONVERSION KIT G.E. WB28K10031</p>
<p><b>GWB28K10214</b></p>  <p>LPG CONVERSION KIT G.E. WB28K10214</p>	<p><b>GWB28K10215</b></p>  <p>LPG CONVERSION KIT G.E. WB28K10215</p>	<p><b>GWB27K10221</b></p> <p>OVEN CONTROL BOARD G.E. WB27K10221</p>	<p><b>GWB27K10245</b></p>  <p>OVEN CONTROL BOARD G.E. WB27K10245</p>	<p><b>GWB27T10211</b></p>  <p>OVEN CONTROL BOARD G.E. WB27T10211</p>
<p><b>GWB27T10276</b></p>  <p>OVEN CONTROL BOARD G.E. WB27T10276 / WB27K5298</p>	<p><b>GWB23T10015</b></p>  <p>OVEN SENSOR G.E. WB23T10015</p>	<p><b>GWB30T10043</b></p>  <p>RANGE HEATER G.E. 1.200W WB30T10043 / WB30K5030</p>	<p><b>GWB30T10047</b></p>  <p>RANGE HEATER G.E. 1.500W WB30T10047</p>	<p><b>GWB30T10045</b></p>  <p>RANGE HEATER G.E. 2.000W WB30T10045</p>



**Galpa Export**  
**GENERAL ELECTRIC RANGE/STOVE/OVEN PARTS**

<p><b>GWB30M1</b></p>  <p>RANGE HEATER G.E. 6" 240V WB30M1</p>	<p><b>G2062.116</b></p>  <p>RANGE HEATER G.E. 6" 240V.SU 115. WB30X356</p>	<p><b>GWB30M2</b></p>  <p>RANGE HEATER G.E. 8" 240V WB30M2</p>	<p><b>GWB30X348</b></p>  <p>RANGE HEATER G.E. 8" 240V WB30X348 (KIT)</p>	<p><b>G2062.118</b></p>  <p>RANGE HEATER G.E. 8" 240V.SU 116. WB30X354</p>
<p><b>GWB44M5</b></p>  <p>RANGE HEATER G.E. WB44M5</p>	<p><b>GWB44X134</b></p>  <p>RANGE HEATER G.E. WB44X134</p>	<p><b>GWB44X200</b></p>  <p>RANGE HEATER G.E. WB44X200</p>	<p><b>GWB44X228</b></p>  <p>RANGE HEATER G.E. WB44X228</p>	<p><b>GWB44X6185</b></p>  <p>RANGE HEATER G.E. WB44X6185 240V 3400W</p>
<p><b>GWB03X25796</b></p>  <p>RANGE KNOB G.E WB03X25796</p>	<p><b>GWB03X25889</b></p>  <p>RANGE KNOB G.E WB03X25889</p>	<p><b>GWB03K10216</b></p>  <p>RANGE KNOB G.E. BLACK WB03K10216</p>	<p><b>GWB02K10006</b></p>  <p>SMALL BURNER BRACKET G.E. WB02K10006 (DISCONTINUED)</p>	<p><b>GWB28K10619</b></p>  <p>SURFACE ORIFICE HOLDER G.E. WB28K10619</p>
<p><b>GPM03X10001</b></p>  <p>UNIVERSAL ELECTRIC AND GAS KNOB KIT PM03X10001 / 3024483</p>	<p><b>GPM3X84</b></p>  <p>UNIVERSAL ELECTRIC KNOB KIT PM3X84</p>	<p><b>GWB19K31</b></p>  <p>VALVE SAFETY G.E. WB19K31</p>		