





















Galpa Export DANFOSS PRESSURE TRANSMITTERS

<p>G060G146566</p>  <p>DANFOSS COMPACT PRESSURE TRANSMITTER FOR MARINE APPLICATIONS MBS3100</p>	<p>G060G4413</p>  <p>DANFOSS COMPACT PRESSURE TRANSMITTER MBS3153 060G4413</p>	<p>G060G3877</p>  <p>DANFOSS COMPACT PRESSURE TRANSMITTER MBS3153, 060G3877</p>	<p>G060G4411</p>  <p>DANFOSS COMPACT PRESSURE TRANSMITTER MBS3153, 060G4411</p>	<p>G060G4412</p>  <p>DANFOSS COMPACT PRESSURE TRANSMITTER MBS3153, 060G4412</p>
<p>G060G1034</p>  <p>DANFOSS CONNECTOR WITH CABLE 16 ft, CONNECTION DIN43650-A, FOR AKS/MBS 060G1034</p>	<p>G060G1037</p> <p>DANFOSS PRESSURE SENSOR AK-CC, 1/4NPT, -14.5 to 174 pslg 060G1037</p>	<p>G060G1133</p>  <p>DANFOSS PRESSURE TRANSMITTER MBS 3000-2211-A1AB04-0</p>	<p>G060G2117</p> <p>DANFOSS PRESSURE TRANSMITTER AKS 33 1/4 NPT, -1-12bar 060G2117</p>	<p>G060G2101</p>  <p>DANFOSS PRESSURE TRANSMITTER AKS33 -1-16BAR, 1/4 NPT PLUG. 060G2101</p>
<p>G060G1136</p>  <p>DANFOSS PRESSURE TRANSMITTER MBS3000 0-10BAR, 1/4" NPT PLUG</p>	<p>G060G1125</p> <p>DANFOSS PRESSURE TRANSMITTER MBS3000 0-10BAR, 1/4" NPT PLUG 060G1125 MBS 3000-2011-A1AB04-0</p>	<p>G060G1142</p>  <p>DANFOSS PRESSURE TRANSMITTER MBS3000 0-150psi S, 1/4" NPT PLUG, 4-20mA, 060G1142</p>	<p>G060G1137</p>  <p>DANFOSS PRESSURE TRANSMITTER MBS3000 0-16BAR, 1/4" NPT PLUG</p>	<p>G060G1563</p>  <p>DANFOSS PRESSURE TRANSMITTER MBS3000 0-1BAR, 1/4" NPT PLUG, 4-20mA, 060G1563, OPERATING TEMP -40 TO 85 C</p>
<p>G060G1143</p>  <p>DANFOSS PRESSURE TRANSMITTER MBS3000 0-200psi S, 1/4" NPT PLUG, 4-20mA, 060G1317</p>	<p>G060G1430</p>  <p>DANFOSS PRESSURE TRANSMITTER MBS3000 0-25BAR, 1/4" G PLUG</p>	<p>G060G1144</p>  <p>DANFOSS PRESSURE TRANSMITTER MBS3000 0-300psi S, 1/4" NPT PLUG, 4-20mA, 060G1144</p>	<p>G060G1123</p>  <p>DANFOSS PRESSURE TRANSMITTER MBS3000 0-4BAR, 1/4" NPT PLUG 060G1123</p>	<p>G060G3946</p>  <p>DANFOSS PRESSURE TRANSMITTER MBS3000 0-600BAR, 1/4" NPT PLUG</p>
<p>G060G1140</p>  <p>DANFOSS PRESSURE TRANSMITTER MBS3000 0-60PSI, 1/4" NPT PLUG</p>	<p>G060G1135</p>  <p>DANFOSS PRESSURE TRANSMITTER MBS3000 0-6BAR, 1/4" NPT PLUG</p>			