

































Galpa Export DANFOSS CONTACTORS

<p>G037H0112</p>  <p>DANFOSS AUXILIARY CONTACT CB-NC FOR CONTACTOR 10A NORMAL CLOSED</p>	<p>G037H0111</p>  <p>DANFOSS AUXILIARY CONTACT CB-NO FOR CONTACTOR 10A NORMAL OPEN</p>	<p>G037H6487</p>  <p>DANFOSS CONTACTOR COIL 110V 50-60HZ FOR DP25, DP30 AND DP40</p>	<p>G037H6087</p>  <p>DANFOSS CONTACTOR COIL 110V 50-60HZ FOR DP50</p>	<p>G037G6087</p>  <p>DANFOSS CONTACTOR COIL 110V 50-60HZ FOR DP50</p>
<p>G037H6488</p>  <p>DANFOSS CONTACTOR COIL 220V 50-60HZ FOR DP25, DP30 AND DP40</p>	<p>G037H6088</p>  <p>DANFOSS CONTACTOR COIL 220V 50-60HZ FOR DP50</p>	<p>G037H6484</p>  <p>DANFOSS CONTACTOR COIL 24V 50-60HZ FOR DP25, DP30 AND DP40</p>	<p>G037H6084</p>  <p>DANFOSS CONTACTOR COIL 24V 50-60HZ FOR DP50</p>	<p>G037H6478</p>  <p>DANFOSS CONTACTOR COIL 440V 50-60HZ FOR DP25, DP30 AND DP40</p>
<p>G037H6078</p>  <p>DANFOSS CONTACTOR COIL 440V 50-60HZ FOR DP50</p>	<p>G047B010266</p>  <p>DANFOSS CONTACTOR COVER + BLOCK, BCI-2, IP-55, FOR CI6 / 30 AND DP-25 TO DP-40</p>	<p>G047B011166</p>  <p>DANFOSS CONTACTOR COVER PUSH BUTTON, BCI-2, IP-55, FOR CI6 / 30 AND DP-25 TO DP-40</p>	<p>G037H415123</p>  <p>DANFOSS CONTACTOR DP25 2 POLES 110V 25A</p>	<p>G037H415132</p>  <p>DANFOSS CONTACTOR DP25 2 POLES 220V 25A</p>
<p>G037H415113</p>  <p>DANFOSS CONTACTOR DP25 2 POLES 24V 25A</p>	<p>G037H415023</p>  <p>DANFOSS CONTACTOR DP25 3 POLES 110V 25A</p>	<p>G037H415032</p>  <p>DANFOSS CONTACTOR DP25 3 POLES 220V 25A</p>	<p>G037H415013</p>  <p>DANFOSS CONTACTOR DP25 3 POLES 24V 25A</p>	<p>G037H415223</p>  <p>DANFOSS CONTACTOR DP30 2 POLES 110V 30A</p>
<p>G037H415232</p>  <p>DANFOSS CONTACTOR DP30 2 POLES 220V 30A</p>	<p>G037H415213</p>  <p>DANFOSS CONTACTOR DP30 2 POLES 24V 30A</p>	<p>G037H415423</p>  <p>DANFOSS CONTACTOR DP30 3 POLES 110V 30A</p>	<p>G037H415432</p>  <p>DANFOSS CONTACTOR DP30 3 POLES 220V 30A</p>	<p>G037H415413</p>  <p>DANFOSS CONTACTOR DP30 3 POLES 24V 30A</p>
<p>G037H415723</p>  <p>DANFOSS CONTACTOR DP40 2 POLES 110V 40A</p>	<p>G037H415732</p>  <p>DANFOSS CONTACTOR DP40 2 POLES 220V 40A</p>	<p>G037H415713</p>  <p>DANFOSS CONTACTOR DP40 2 POLES 24V 40A</p>	<p>G037H415623</p>  <p>DANFOSS CONTACTOR DP40 3 POLES 110V 40A</p>	<p>G037H415632</p>  <p>DANFOSS CONTACTOR DP40 3 POLES 220V 40A</p>



Galpa Export DANFOSS CONTACTORS

G037H415613



DANFOSS CONTACTOR DP40 3
POLES 24V 40A

G037H415923



DANFOSS CONTACTOR DP50 3
POLES 110V 50A

G037H415932



DANFOSS CONTACTOR DP50 3
POLES 220V 50A

G037H415913



DANFOSS CONTACTOR DP50 3
POLES 24V 50A