



Galpa Export DANFOSS OVERLOAD RELAYS

G047H0200  DANFOSS OVERLOAD RELAY TI16C 0.13-0.20A FOR DP25, DP30 AND DP40	G047H0201  DANFOSS OVERLOAD RELAY TI16C 0.19-0.29A FOR DP25, DP30 AND DP40	G047H0202  DANFOSS OVERLOAD RELAY TI16C 0.27-0.42A FOR DP25, DP30 AND DP40	G047H0203  DANFOSS OVERLOAD RELAY TI16C 0.40-0.62A FOR DP25, DP30 AND DP40	G047H0204  DANFOSS OVERLOAD RELAY TI16C 0.60-0.92A FOR DP25, DP30 AND DP40
G047H0205  DANFOSS OVERLOAD RELAY TI16C 0.85-1.30A FOR DP25, DP30 AND DP40	G047H0206  DANFOSS OVERLOAD RELAY TI16C 1.20-1.90A FOR DP25, DP30 AND DP40	G047H0207  DANFOSS OVERLOAD RELAY TI16C 1.80-2.80A FOR DP25, DP30 AND DP40	G047H0212  DANFOSS OVERLOAD RELAY TI16C 11.00-16.00A FOR DP25, DP30 AND DP40	G047H0208  DANFOSS OVERLOAD RELAY TI16C 2.70-4.20A FOR DP25, DP30 AND DP40
G047H0209  DANFOSS OVERLOAD RELAY TI16C 4.00-6.20A FOR DP25, DP30 AND DP40	G047H0210  DANFOSS OVERLOAD RELAY TI16C 6.00-9.20A FOR DP25, DP30 AND DP40	G047H0211  DANFOSS OVERLOAD RELAY TI16C 8.00-12.00A FOR DP25, DP30 AND DP40	G047H0213  DANFOSS OVERLOAD RELAY TI25C 15.00-20.00A FOR DP30 AND DP40	G047H0214  DANFOSS OVERLOAD RELAY TI25C 19.00-25.00A FOR DP30 AND DP40
G047H0215  DANFOSS OVERLOAD RELAY TI30C 24.00-32.00A FOR DP40	G047H1013  DANFOSS OVERLOAD RELAY TI80 16.00-23.00A FOR DP50	G047H1014  DANFOSS OVERLOAD RELAY TI80 22.00-32.00A FOR DP50	G047H1015  DANFOSS OVERLOAD RELAY TI80 30.00-45.00A FOR DP50	G047H1016  DANFOSS OVERLOAD RELAY TI80 42.00-63.00A FOR DP50