

























Galpa Export Danfoss Frequency Converters

<p>G175G5539</p>  <p>Danfoss Soft Starter Mcd 500 175g5539 200-525 Vac, 380a, Ac53a</p>	<p>G131F5460</p>  <p>Danfoss Vlt 15hp 200-240v 46.2a 20ip Fc-102p11kt2e20h2xgx</p>	<p>G131F0426</p>  <p>Danfoss Vlt 15hp 380-480v 24.0a 20ip Fc-102p11kt4e20h2xgx</p>	<p>G175G5233</p>  <p>Danfoss Vlt 25hp 200-525v 42a 20ip Mcd202018t6cv3</p>	<p>G131H5694</p>  <p>Danfoss Vlt 30hp 200-240v 88.0a 20ip Fc-102p22kt2e20h2xgx</p>
<p>G131F6626</p>  <p>Danfoss Vlt 30hp 380-480v 44.0a 20ip Fc-102p22kt4e20h2xgx</p>	<p>G131B7004</p>  <p>Danfoss Vlt 50hp 380-480v 73.0a Ip21 37kw Fc-102p37kt4e21h2xgxxxxxxxabxxxxxx</p>	<p>G131F6756</p>  <p>Danfoss Vlt 50hp 380-480v 73.0a Ip66 37kw Fc-102p37kt4e66h2xgxxxxxxxabxxxxxx</p>	<p>G134F9363</p>  <p>Danfoss Vlt Automation Drive 134f9363 3x380-500v Ip20 Fc-302p18kt20h2</p>	<p>G131B0003</p>  <p>Danfoss Vlt Automation Drive Fc-302 7.5kw 3x380-500v Ip20 Fc-302p7k5t5e20h1xxxxxxxabxxxxxx</p>
<p>G130B1107</p>  <p>Danfoss Vlt Control Panel LCP 102 130B1107</p>	<p>G132F0003</p>  <p>Danfoss Vlt Fc-051 0.75kw 200-2400v</p>	<p>G132F0059</p>  <p>Danfoss Vlt Fc-051 15kw/31amps 20hp 380-480v</p>	<p>G131B9826</p>  <p>Danfoss Vlt Fc-302 11kw 3x380-500v Ip20 Fc-302p11kt5e20h1xgxxxxxxxabxxxxxx</p>	<p>G131B0328</p>  <p>Danfoss Vlt Fc-302 3.7kw 200-240v Ip20 Fc-302p7k2e20h1b</p>
<p>G131B0070</p>  <p>Danfoss Vlt Fc-302 4.0kw/10amps 380-500v Ip20 Fc-302p4k0t5e20h2bgxxxxxxxabxxxxxx</p>	<p>G131B0004</p>  <p>Danfoss Vlt Fc-302 7.5kw 380-500v Fc-302p7k5t5e20h1bxx</p>	<p>G131B0042</p>  <p>Danfoss Vlt Fc-302 7.5kw/16amps 380-500v</p>	<p>G134X8222</p>  <p>Danfoss Vlt Frequency Driver FC 302 250hp 380-500 vac FC-302N250T5E5MH4XGC3XXSXXX VLT Automation Drive FC- 302 250 KW / 350 HP, 380</p>	<p>G131L9798</p>  <p>Danfoss Vlt Hvac Fc-101 5.5kw/ 200-240v, Ip20, Rfi A1 Fc-101p5k5e20h4xxxxxxxabxxxxxx</p>
<p>GMCD5-0141B</p>  <p>Danfoss Vlt Mcd5-0141b Soft Starter 96a 75hp / 440v</p>	<p>G195N1123</p>  <p>Danfoss Vlt-2881 20hp 15kw 380-480v / 195n1123</p>	<p>G132B0254</p> <p>Vlt Control Panel Lcp21</p>		