









## Galpa Export Danfoss Electronics Products

<p><b>G2401.AKCM</b></p>  <p>Control Module For Elec. Control Danfoss Ak-Sc255/Ak-Cm</p>	<p><b>G068F0541</b></p> <p>Danfoss Armature Kit For Electric Expansion Valve Akv 10 068f0541</p>	<p><b>G068F5045</b></p> <p>Danfoss Armature Kit For Electric Expansion Valve Akv 15 068f5045</p>	<p><b>G068F1210</b></p> <p>Danfoss Electric Expansion Valve Akv 10-1 R22, R134a, R404a 3/8"X1/2" Odf 068f1210</p>	<p><b>G068F1164</b></p> <p>Danfoss Electric Expansion Valve Akv 10-2 R22, R134a, R404a 3/8"X1/2" Odf 068f1164</p>
<p><b>G068F1213</b></p> <p>Danfoss Electric Expansion Valve Akv 10-2 R22, R134a, R404a 3/8"X1/2" Odf 068f1213</p>	<p><b>G068F1167</b></p> <p>Danfoss Electric Expansion Valve Akv 10-3 R22, R134a, R404a 3/8"X1/2" Odf 068f1167</p>	<p><b>G068F1216</b></p> <p>Danfoss Electric Expansion Valve Akv 10-3 R22, R134a, R404a 3/8"X1/2" Odf 068f1216</p>	<p><b>G068F1170</b></p> <p>Danfoss Electric Expansion Valve Akv 10-4 R22, R134a, R404a 3/8"X1/2" Odf 068f1170</p>	<p><b>G068F1219</b></p> <p>Danfoss Electric Expansion Valve Akv 10-4 R22, R134a, R404a 3/8"X1/2" Odf 068f1219</p>
<p><b>G068F1173</b></p> <p>Danfoss Electric Expansion Valve Akv 10-5 R22, R134a, R404a 3/8"X1/2" Odf 068f1173</p>	<p><b>G068F1222</b></p> <p>Danfoss Electric Expansion Valve Akv 10-5 R22, R134a, R404a 3/8"X1/2" Odf 068f1222</p>	<p><b>G068F1225</b></p> <p>Danfoss Electric Expansion Valve Akv 10-6 R22, R134a, R404a 3/8"X1/2" Odf 068f1225</p>	<p><b>G068F1228</b></p> <p>Danfoss Electric Expansion Valve Akv 10-7 R22, R134a, R404a 1/2"X5/8" Odf 068f1228</p>	<p><b>G068F5035</b></p> <p>Danfoss Electric Expansion Valve Akv 15-1 R22, R134a, R404a 3/4"X3/4" Odf 068f5035</p>
<p><b>G068F5036</b></p> <p>Danfoss Electric Expansion Valve Akv 15-2 R22, R134a, R404a 3/4"X3/4" Odf 068f5036</p>	<p><b>G068F5037</b></p> <p>Danfoss Electric Expansion Valve Akv 15-3 R22, R134a, R404a 7/8"X7/8" Odf 068f5037</p>	<p><b>G068F5038</b></p> <p>Danfoss Electric Expansion Valve Akv 15-4 R22, R134a, R404a 1-1/8"X1-1/8" Odf 068f5038</p>	<p><b>G068F4079</b></p> <p>Danfoss Electric Expansion Valve Akvh 10-1 Co2 3/8"X1/2" Odf 068f4079</p>	<p><b>G068F4080</b></p> <p>Danfoss Electric Expansion Valve Akvh 10-2 Co2 3/8"X1/2" Odf 068f4080 / 068f5212</p>
<p><b>G068F4081</b></p> <p>Danfoss Electric Expansion Valve Akvh 10-3 Co2 3/8"X1/2" Odf 068f4081 / 068f5213</p>	<p><b>G068F4082</b></p> <p>Danfoss Electric Expansion Valve Akvh 10-4 Co2 3/8"X1/2" Odf 068f4082 / 068f5214</p>	<p><b>G068F4083</b></p> <p>Danfoss Electric Expansion Valve Akvh 10-5 Co2 3/8"X1/2" Odf 068f4083 / 068f5215 / 068f5235</p>	<p><b>G068F4084</b></p> <p>Danfoss Electric Expansion Valve Akvh 10-6 Co2 3/8"X1/2" Odf 068f4084 / 068f5216</p>	<p><b>G084N2043</b></p> <p>Danfoss Electronic Control Sensor Aks 21 2.5mts 084n2043</p>
<p><b>G042H2029</b></p> <p>Danfoss Electronic Expansion Valve AKV 20-5 Nc, R22, R134a, R404a 2-1/8 in x 2-1/8 in Coil Not Included 042H2029</p>	<p><b>G068F5029</b></p> <p>Danfoss Electronic Expansion Valve Akva 15-4 Nc, R22, R134a, R404a 1"X1" Flange Connection 068f5029</p>	<p><b>G042H2103</b></p> <p>Danfoss Electronic Expansion Valve Akva 20-3 Nc, R22, R134a, R404a 1-1/4"X1-1/4" Coil Not Included 042h2103</p>	<p><b>G068F3268</b></p> <p>Danfoss Electronic Expansion Valve Akva10-8 068f3268</p>	<p><b>G068F0540</b></p> <p>Danfoss Filter And Gasket Kit For Electric Expansion Valve Akv 068f0540</p>

















# Galpa Export Danfoss Electronics Products

<b>G2401.AKS41-8</b>  Danfoss Level Sensor Aks 41-8, Includes Gasket And 1" Connection, 084h4058	<b>G068F5283</b>  Danfoss Orifice For Electric Expansion Valve Akv 10, No. 0 To 3, 068f5283	<b>G068F5284</b>  Danfoss Orifice For Electric Expansion Valve Akv 10, No. 4 To 6, 068f5284	<b>G068F5285</b>  Danfoss Orifice For Electric Expansion Valve Akv 10, No. 7 To 8, 068f5285	<b>G068F5268</b>  Danfoss Orifice For Electric Expansion Valve Akv 15, No. 4 To 6, 068f5268
<b>G068F5265</b>  Danfoss Orifice For Electric Expansion Valve Akv 15-1 068f5265	<b>G068F5266</b>  Danfoss Orifice For Electric Expansion Valve Akv 15-2 068f5266	<b>G068F5267</b>  Danfoss Orifice For Electric Expansion Valve Akv 15-3 068f5267	<b>G060G3804</b>  Danfoss Pressure Transmitter AKS 32, Pressure connection notes: Type: NPT, Pressure Connection Size: 1/4-18 0 - 13.79 BAR 0 -	<b>G060G6556</b>  Danfoss Pressure Transmitter AKS 32R, 0 a 350 psi 7/16 UNF 336078351 Replace 060G6556 333992051 333992051 331764511
<b>G060G6555</b>  Danfoss Pressure Transmitter AKS 32R, 0 a 435 psi 0 a 30 bar 336078342 Replaces Daikin 333992042 060G6555 10000109563 3339934122	<b>G060G6554</b>  Danfoss Pressure Transmitter AKS 32R, 7/16 UNF, -14,5 -101,5psi	<b>G060G0090</b>  Danfoss Pressure Transmitter AKS 32R, Pressure connection notes: Flare 1/4 in, Pressure Connection Size: 7/16-20	<b>G084B8534</b>  Electronic Control Danfoss Ak-Cc 210, Txv, Single Evaporator, 4 Outputs, 3 Sensors, 115v	<b>G084B8520</b>  Electronic Control Danfoss Ak-Cc 210, Txv, Single Evaporator, 4 Outputs, 3 Sensors, 220v 084b8520
<b>G084B8528</b>  Electronic Control Danfoss Ak-Cc 250, Modbus Data Communication	<b>G084B8036</b>  Electronic Control Danfoss Ak-Cc 550a, Akv, Single Evaporator, 5 Outputs+Akv, 6 Sensors, 115v 084b8036	<b>G084B8030</b>  Electronic Control Danfoss Ak-Cc 550a, Akv, Single Evaporator, 5 Outputs+Akv, 6 Sensors, 230v 084b8030	<b>G080Z0139</b>  Electronic Control Danfoss Ak-Cc 750, Akv, Multiple Evaporator, 8 Outputs 4 Akv, 11 Sensors, 24v Ac/Dc Lon	<b>G080Z0130</b>  Electronic Control Danfoss Ak-Cc 750, Akv, Multiple Evaporator, 8 Outputs 4 Akv, 11 Sensors, 24v Ac/Dc Lon
<b>G080Z0063</b>  Electronic Control Danfoss Ak-Cm 101c	<b>G2401.AKPC530</b>   Electronic Control Danfoss Ak-Pc530 24v/50-60hz	<b>G2401.AKSC255</b>   Electronic Control Danfoss Ak-Sc255	<b>G2401.AKSC355</b>   Electronic Control Danfoss Ak-Sc355	<b>G2401.AKSC355B</b>  Electronic Control Danfoss Ak-Sc355 No Display
<b>G080Z4105</b>  Electronic Control Danfoss Ak-Sm 800	<b>G080Z4001</b>  Electronic Control Danfoss Ak-Sm 850, Full Store, 100-240v	<b>G080Z4008</b>  Electronic Control Danfoss Ak-Sm 880, Full Store, 100-240v	<b>G080Z4009</b>   Electronic Control Danfoss Ak-Sm 880, Full Store/ Retro-Fit Tp78, 100-240v	<b>G2401.AKSM350</b>   Electronic Control Danfoss Ak-Sm350



# Galpa Export Danfoss Electronics Products

<p><b>G080Z008</b></p> <p>Electronic Control Danfoss Ak-Xm 102a Low</p>	<p><b>G080Z0013</b></p> <p>Electronic Control Danfoss Ak2-Xm 102 B</p>	<p><b>G2401.AKXM1</b></p> <p>Extension Module For Elec. Control Danfoss Ak-Sc255/ Ak-Xm 101ab</p>	<p><b>G2401.AKXM</b></p>  <p>Extension Module For Elec. Control Danfoss Ak-Sc255/ Ak-Xm 205b</p>	<p><b>G2401.AK2XM</b></p>  <p>Extension Module For Elec. Control Danfoss Ak-Sc255/ Ak2-Xm</p>
<p><b>G2401.AKXM100</b></p>  <p>Extension Module For Elec. Control Danfoss Ak-Xm 100 / 080z0032</p>	<p><b>G080Z2995</b></p> <p>Gas Detector Danfoss Dgs-Ir-Co2 Gas Detector Ip 41, Modbus, 080Z2995 / 080Z2800</p>	<p><b>G2401.AKS3991</b></p> <p>High Pressure Sensor For Control Danfoss Ak-Sm350</p>	<p><b>G2401.AK2S</b></p>  <p>Humidity Sensor For Elec. Control Danfoss Ak-Sc255</p>	<p><b>G2401.AKS399</b></p> <p>Low Pressure Sensor For Control Danfoss Ak-Sm350</p>
<p><b>G080Z0170</b></p> <p>Monitoring Unit, Type: Ak-Lm 330, 24v, 080z0170 Logging Module, Monitoring, Communication Type: Lon Rs485;Rs232</p>	<p><b>G080Z0186</b></p> <p>Pack Controller, Type: Ak-Pc 781, 24v, Pack W. Heat Reclaim, Communication Type: Io Extension;Lon Rs485, 080z0186</p>	<p><b>G2401.4153</b></p> <p>Phase Protector For Control Danfoss Ak-Sc255 / Ak-Sc355</p>	<p><b>G2401.AK2</b></p>  <p>Photo Cel For Elec. Control Danfoss Ak-Sc255</p>	<p><b>G2401.AKPS</b></p>  <p>Power Supply For Electronic Control Danfoss Ak-Sc255/ Ak-Ps</p>
<p><b>G2401.AKS32</b></p>  <p>Pressure Sensor For Electronic Control Danfoss Aks 32</p>	<p><b>G2401.AKS321</b></p>  <p>Pressure Sensor For Electronic Control Danfoss Aks 32 cable length 315in</p>	<p><b>G060G3551</b></p> <p>Pressure Sensor For Electronic Control Danfoss Aks 32r</p>	<p><b>G2401.AKS33</b></p>  <p>Pressure Sensor For Electronic Control Danfoss Aks 33</p>	<p><b>G2401.AKS12K</b></p> <p>Sensor For Elec. Control Danfoss Ak-Sc255/ Aks 12 1.5mt Kit</p>
<p><b>G2401.AKS12</b></p>  <p>Sensor For Electronic Control Danfoss Ak-Sc255, Ak-Cc, Akv, Aks 12 5ft. / 1.5mt 084n0035</p>	<p><b>G2401.AKS12-3.5</b></p>  <p>Sensor For Electronic Control Danfoss Ak-Sc255/ Aks 12 3.5mt</p>	<p><b>G2401.AKS11-5.5</b></p> <p>Sensor For Electronic Control Danfoss Aks 11 / Pt1000, 084n0005 , 5.5mt</p>	<p><b>G2401.AKS11-3.5</b></p>  <p>Sensor For Electronic Control Danfoss Aks 11 / Pt1000, 084n0027, 080z0027. 3.5mt</p>	<p><b>G084N0008</b></p> <p>Sensor For Electronic Control Danfoss Aks 11, 084n0008. 8.5mt</p>
<p><b>G084N0036</b></p> <p>Sensor For Electronic Control Danfoss Aks 12 - 1.5m Pt1000 Adap 084n0036</p>	<p><b>G2401.EKS211</b></p>  <p>Sensor For Electronic Control Danfoss Eks 211 1.5mt -40c(-40f) To 80c(176f) 084b4403 084N1220</p>	<p><b>G084Z7015</b></p>  <p>Sensor For Electronic Control Danfoss Mbt 153</p>	<p><b>G2401.12502</b></p> <p>Split Core For Control Danfoss 200a Ak-Sc255 / Ak-Sc355</p>	<p><b>G2401.12504</b></p> <p>Split Core For Control Danfoss 400a Ak-Sc255 / Ak-Sc355</p>



**Galpa Export**  
**Danfoss Electronics Products**

<b>G2401.50150</b>	<b>G060G0008</b>	<b>G060G1036</b>	<b>G2401.4062</b>
Split Core For Control Danfoss Ak-Sc255	Transducer Connector Danfoss Aks32r / Mb S	Transducer Danfoss Aks32r, 1/12bar S/Conn. Din 1/4	Voltage Regulator For Control Danfoss Ak-Sc255 / Ak-Sc355