



Galpa Export ECOX DUCT AIR CONDITIONERS PARTS

<p>G1111.TUEG36</p>  <p>AXIAL FLOW FAN 36.000 BTU AIR HANDLER ECOX</p>	<p>G1111.TUEG60</p>  <p>AXIAL FLOW FAN 60.000 BTU AIR HANDLER ECOX</p>	<p>GTEFAWNXXXV3</p>  <p>ECOX THERMOSTAT FOR FAN COIL 220V</p>	<p>GTEDIBNXXSV1</p>  <p>ECOX THERMOSTAT, NON-PROGRAMMABLE, 1 STAGE, 24V</p>	<p>GTEDIBP52SV1</p>  <p>ECOX THERMOSTAT, PROGRAMMABLE 5+2, 1 STAGE, 24V</p>
<p>GTEDIBP52MV1</p>  <p>ECOX THERMOSTAT, PROGRAMMABLE 5+2, 2 STAGE, 24V</p>	<p>GTETSBP70SV1</p>  <p>ECOX THERMOSTAT, PROGRAMMABLE 7+0, 1 STAGE, TOUCH SCREEN 24V</p>	<p>G1111.MFC18</p>  <p>MOTOR FAN COIL ECOX MTA4-18CR</p>	<p>G1111.MFC24</p>  <p>MOTOR FAN COIL ECOX MTA4-24CR</p>	<p>G1111.MFC48</p>  <p>MOTOR FAN COIL ECOX MTA4-48CR</p>
<p>G1111.M3006X1</p>  <p>MOTOR YDK-300-6X-1 300W 230V/60HZ MRA-60CW</p>	<p>G1111.MFC36</p>  <p>MOTOR YSK-105-6W 105W 230V/50-60HZ MTA4-36CR</p>	<p>G1111.MFC60</p>  <p>MOTOR YSK-59-6A 220V MTA2-60CR</p>	<p>G1111.MFC604</p>  <p>MOTOR YSK230-6W 220V MTA4-60CR</p>	<p>G1111.TEG</p>  <p>PC BOARD FOR ECOX ALL NAHU MODELS</p>
<p>G1111.TFC</p>  <p>PC BOARD FOR FAN COIL ECOX MTA4</p>	<p>G1111.CFC</p>  <p>REMOTE CONTROL FAN COIL R11CQ</p>	<p>G1111.SCEG</p>  <p>SENSOR FOR AIR HANDLER ECOX (COLD)</p>	<p>G1111.SCT</p>  <p>SENSOR FOR CEILING/FLOOR ECOX (COLD)</p>	<p>G1111.SCTA</p>  <p>SENSOR FOR CEILING/FLOOR ECOX (HOT)</p>
<p>G1111.SMSI-2</p>  <p>SENSOR FOR INVERTER ECOX MSI-12/ MSI-18/ MSI-24</p>	<p>G1111.SFC</p>  <p>SENSOR ROOM TEMPERATURE INDOOR UNIT COPPER TIP BLACK CONNECTOR 35 INCH ECOX GX-600 / 202440500004 / 11201007000136 /</p>	<p>G1111.SMSI</p>  <p>TEMP SENSOR FOR INVERTER ECOX MSI-12/ MSI-18/ MSI-24</p>		